


	PART No.	DESCRIPTION	SPECIFICATION
	<p>WIR-3110 Infrared Setting Unit</p>	<ul style="list-style-type: none"> • The Infrared Setting Unit is used to set the input devices target to an output address or group code. • A infrared signal is used to read and write the address or code information. • All Input Devices have an infrared transceiver built in that is compatible with the Infrared Setting Unit. • Point the Unit at the device to be set, and press the receive information button to identify the device and its contents to the Infrared Setting Unit. Then make edits as required and send the new settings back into the device. 	<p>Power</p> <ul style="list-style-type: none"> • 2 AA standard alkaline or rechargeable NiMH batteries. <p>Communication</p> <ul style="list-style-type: none"> • Infrared communication to Dialog devices equipped with IR transceiver. <p>Interface & Operation</p> <ul style="list-style-type: none"> • IR Setting Unit can request, via IR link, from the device what type it is, display the options available edit and send those options back to the device. • Settings include but are not limited to: <ul style="list-style-type: none"> - display present device target. - set device address or group target. - adjust device settings.

WIR-3110 Infrared Setting Unit

Use to set output address or group codes into Input Devices. Input Devices include: switches, occupancy sensors contact inputs and photo sensors.

IR Transceiver

Built-in IR transceiver for setting target address, group code and preset code of an input device.



Environment

- Non-vibrating, non-corrosive atmosphere & non-condensing humidity.
- Ambient temp: 5°F to +120° F (-15° C to +50° C).

DIMENSIONS & MOUNTING

